

10 MOOC

DETAILS

DEPTH: 1"

LOAD: Top Load.
Fabric is tucked into the track at the outside edge of an outside corner.

USAGE: Outside Corners. The fabric can be stretched over this track at an outside corner to create a "seamless" look, or two fabrics can be tucked into the track to transition from one fabric to another.

EDGE: Square

EDGE WRAPPING:
Not Required.

