

10
MOSL

DETAILS

DEPTH: 1"

LOAD: Side Load.
The fabric is tucked into the track from the side to create a reveal.

USAGE: Midwall track. Use to create a reveal between fabric panels.

EDGE: Square

EDGE WRAPPING:
Only required when the edge is exposed.

Note: When using thick fabrics hold track off the opposing wall or ceiling the thickness of the fabric to allow tucking.

